



StreakStoppers Installation Instructions

As Easy as 1 – 2 - 3

1. Partially release rub rail by loosening screws.
2. Remove the 3M adhesive backing strip on the StreakStopper and slide the straight edge under the rail at each drainage point.
3. Tighten rub rail screws to secure in place.

That's all? Yes, it's as simple as that. Three easy steps and you'll be preventing black hull streaks instead of scrubbing them off.